

# AIRPORT DIAGRAM

## BIRMINGHAM-SHUTTLESWORTH INTL (BHM)

AL-50 (FAA)



BIRMINGHAM, ALABAMA

ATIS  
 119.4 270.1  
 BIRMINGHAM TOWER  
 119.9 317.725  
 GND CON  
 121.7 348.6  
 CLNC DEL  
 125.675 305.2



RWY 06-24  
 PCN 65 F/C/X/T  
 S-175, D-205, 2D-350  
 RWY 18-36  
 PCN 45 F/C/X/T  
 S-75, D-170, 2D-240

JANUARY 2020  
 ANNUAL RATE OF CHANGE  
 0.1° W



CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.  
 READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

SE-4, 21 MAR 2024 to 18 APR 2024

SE-4, 21 MAR 2024 to 18 APR 2024

# AIRPORT DIAGRAM

## BIRMINGHAM-SHUTTLESWORTH INTL (BHM)

BIRMINGHAM, ALABAMA